

MotoReva

Tool # MT-103

SlimStand



Step 1. The Slimstand™ is installed on the motorcycle while it is resting on its sidestand. The best bet is to approach the bike from rear, and install the stand and rear axle pin:



Step 2. Move around to the left hand side of the bike, as you would to use a normal center stand. Use your right foot to brace the forward tube of the Slimstand™. Then using the normal grab rails, lift the motorcycle rearward and slightly upward. The Slimstand™ will roll over top center slightly and then rest securely on the stand.



The action to place the motorcycle on the Slimstand™ is much like that of placing a motorcycle on a centerstand. After a few repetitions, it becomes quite easy.